



INSTALLATION INSTRUCTIONS

LRP2L

PHI LATCH MONITORING SWITCH KIT

MODELS: 2200 & 2800 VERTICAL ROD DEVICES

Remove head cover. Install Switch Bracket using supplied screws, inserting the longer screw through supplied cable tie. Route wires through tie. Re-attach head cover.

NOTE: Regardless of handing, the Switch Bracket is always attached to the top side of the device head. The Switch Lever may require adjustment after installation of vertical rods.

