801 Avenida Acaso, Camarillo, Ca. 93012 • (805) 494-0622 • www.sdcsecurity.com • E-mail: service@sdcsecurity.com

INSTALLATION WIRING DIAGRAM FB-4 and FB4DC FUSED TERMINAL BOARDS

The FB-4 provides four (4) individually fused outputs for modular system protection. A 2 amp fuse is supplied for each of the 4 fused outputs. Determine the load requirement for each output and change the fuse with a different rating as needed. The output voltage supplied to each output is the same as the voltage input. The total current required for all of the outputs must not exceed the power supply output current rating.

The FB4DC includes an integrated full wave bridge rectifier to allow the use of an AC transformer or a DC power supply to provide a DC output voltage.

