



INSTALLATION INSTRUCTIONS



.865"


BACK SET:







DOOR PREPATATION



.865"


BACK SET:



INSTRUCTIONS FOR REVERSING THE MOUNTING BLOCK

Remove the Cylinder locking set screw, and unfasten the Mortise Cylinder out of the Mounting Block.

Remove the screws securing the Mounting Block and the Sliding Link Block.



Make sure the sliding Link Block is positioned properly


Reverse the components and re-install as shown.




LOCK WIRING

Select 24VDC OR 12VDC Configuration, and use provided pigtail connector:

24VDC SOLENOID CONFIGURATION



12VDC SOLENOID CONFIGURATION



Electrical Data

Dual Voltage Solenoid:

12VDC @ .9 Amp (Max) Continuous Duty 24VDC @ .45 Amp (Max) Continuous Duty

OPTIOINAL BOLT POSITION SENSOR (BPS-MAGNETIC)

B Indicates bolt locked or unlocked 5 Watt

OPTIOINAL DOOR POSITION SWITCH (DPS-MECHANICAL)

D Indicates door opened or closed 4A @ 30VDC (Resistive)

* When both options are ordered the Common is shared.

DPS / BPS CONFIGURATION

